

## Trailing Edge Bell-Press LED Dimmer (125W, 500W and 800W) Summary of Settings

- **2 x bell-presses**  
Turn lamp on to 50% intensity, irrespective of previous state – mostly for use with Shuttle Master Zone Controller (MZC)
- **7 x bell-presses** (\*1)  
Auto setting for the Synerji LED's
- **9 x bell-presses** (\*2)  
Set the minimum dim level to lower than factory default
- **11 x bell-presses** (\*3)  
Set the minimum dim level to a user selected level
- **13 x bell-presses** (\*2)  
Reset all settings to factory default
- **15 x bell-presses**  
Compatibility mode for certain electronic transformer/LED combinations
- **17 x bell-presses** (\*4)  
Set the maximum dim level to a user selected level

(\*1) *Setting required if flickering of Synerji lamps are encountered. If the dimmer accepts the setting, the lamps will turn off and then automatically turn on*

(\*2) *Tip – first dim to a low intensity. If the dimmer accepts the setting, the lamps will go to full intensity.*

(\*3) *If the dimmer accepts the setting, the lamps will go to full intensity*

(\*4) *If the dimmer accepts the setting, the lamps will go to minimum intensity*